










## Wall Cabinets | 12" Deep

<div>Design Tips:</div> <ul style="list-style-type: none"><li>• Apply an End Panel Skin to create a flush end on the side of a Wall cabinet if installed at the end of a run for ease of Moulding installation</li><li>• All single-door cabinets are hinged left</li><li>• Cabinets can be flipped during installation for right hinge applications</li></ul>			SMARTSHIELD				BIRCH					
			ELLSTON	ELLIOT	CARVER	LIVINGSTON EMERY	DARROW		FREMONT		WINSLOW	
	SKU	cubes	\$	\$	\$	\$	Stain	Paint	Stain	Glaze	Stain	
WALL - 21" HIGH - 12" DEEP												
	<ul style="list-style-type: none"><li>• Two butt doors</li><li>• Shelves not available</li><li>• Available widths: 30"-36"</li></ul>	W3021B	5.4	422	434	538	611	434	487	468	538	487
		W3321B	5.9	432	445	555	629	445	502	479	555	502
		W3621B	6.5	444	456	570	645	456	515	495	570	515
	<ul style="list-style-type: none"><li>• Two doors, cabinet with center stile</li><li>• Shelves not available</li><li>• Available width: 39"</li></ul>	W3921	6.9	467	480	600	682	480	541	519	600	541
WALL - 24" HIGH - 12" DEEP												
	<ul style="list-style-type: none"><li>• One door</li><li>• One adjustable shelf</li><li>• Available widths: 15"-24"</li></ul>	W1524	3.2	318	326	403	456	326	365	350	403	365
		W1824	3.8	337	345	428	494	345	387	373	428	387
		W2124	4.4	361	370	459	526	370	413	396	459	413
		W2424	5.0	381	393	487	552	393	443	427	487	443
	<ul style="list-style-type: none"><li>• Two butt doors</li><li>• One adjustable shelf</li><li>• Center shelf support clip included</li><li>• Available widths: 27"-36"</li></ul>	W2724B	5.6	399	409	514	585	409	465	444	514	465
		W3024B	6.2	422	434	538	611	434	487	468	538	487
		W3324B	6.8	438	451	564	638	451	507	487	564	507
		W3624B	7.4	456	470	587	664	470	532	509	587	532
	<ul style="list-style-type: none"><li>• Two doors, cabinet with center stile</li><li>• One adjustable shelf</li><li>• Center shelf support clip included</li><li>• Available widths: 39"-48"</li></ul>	W3924	8.0	486	500	622	714	500	561	539	622	561
		W4224	8.5	511	526	660	761	526	598	571	660	598
		W4824	9.7	573	591	744	849	591	665	639	744	665
WALL - 27" HIGH - 12" DEEP												
	<ul style="list-style-type: none"><li>• Two butt doors</li><li>• One adjustable shelf</li><li>• Center shelf support clip included</li><li>• Available width: 30"</li></ul>	W3027B	6.9	450	464	581	656	464	524	503	581	524
WALL - 30" HIGH - 12" DEEP												
	<ul style="list-style-type: none"><li>• One door</li><li>• Two adjustable shelves</li><li>• Available widths: 9"-24"</li></ul>	W0930	2.5	309	318	389	436	318	351	340	389	351
		W1230	3.2	309	318	389	436	318	351	340	389	351
		W1530	3.9	333	342	422	477	342	382	369	422	382
		W1830	4.7	359	368	454	519	368	408	393	454	408
		W2130	5.4	379	389	480	542	389	441	424	480	441
		W2430	6.2	407	417	521	596	417	472	453	521	472
	<ul style="list-style-type: none"><li>• Two butt doors</li><li>• Two adjustable shelves</li><li>• Center shelf support clip included on 27" wide and greater</li><li>• Available widths: 24"-36"</li></ul>	W2430DD	6.2	437	450	568	658	450	506	486	568	506
		W2730B	6.9	445	457	573	648	457	517	498	573	517
		W3030B	7.6	457	471	589	666	471	533	510	589	533
		W3330B	8.4	496	511	641	734	511	580	556	641	580
		W3630B	9.1	511	526	660	753	526	598	571	660	598
	<ul style="list-style-type: none"><li>• Two doors, cabinet with center stile</li><li>• Two adjustable shelves</li><li>• Center shelf support clip included</li><li>• Available widths: 39"-48"</li></ul>	W3930	9.9	541	557	701	792	557	629	601	701	629
		W4230	10.6	556	573	722	818	573	648	619	722	648
		W4530	11.3	602	620	783	903	620	705	675	783	705
		W4830	12.1	615	633	796	920	633	719	688	796	719