

## Drawer Fronts

## PARTS AND ACCESSORIES

SKU	OAK		MAPLE														
	HAVEN	OXFORD	HAVEN		OXFORD		MILTON		DOVER			JEFFERSON & WINDSOR			GRANTLEY		
	stain	stain	stain	point	stain	point	stain	point	stain	stain w/glaze	point or point w/glaze	stain	stain w/glaze	point or point w/glaze	stain	stain w/glaze	point or point w/glaze
DRAWER FRONT – 6" WIDE																	
DRWF0606	17	19	17	22	19	24	20	25	35	40	44	20	23	25	32	36	40
DRAWER FRONT – 9" WIDE																	
DRWF0906	20	22	23	29	24	30	24	30	46	52	58	33	37	42	47	53	59
DRAWER FRONT – 10" WIDE																	
DRWF1006	24	28	26	33	28	35	25	32	46	52	58	36	41	45	49	55	62
DRAWER FRONT – 12" WIDE																	
DRWF1206	25	29	27	34	30	38	27	34	50	56	63	37	42	47	51	58	64
DRWF1210	31	35	32	40	35	44	34	43	57	64	72	44	50	55	63	71	79
DRWF1212	32	35	34	43	37	47	37	47	60	68	75	46	52	58	66	74	83
DRAWER FRONT – 15" WIDE																	
DRWF1506	28	31	30	38	32	40	31	39	56	63	70	41	46	52	54	61	68
DRWF1510	33	36	35	44	39	49	40	50	63	71	79	48	54	60	68	77	85
DRWF1512	35	38	38	48	41	52	44	55	67	76	84	50	56	63	70	79	88
DRWF1515	34	36	40	50	44	55	51	64	61	69	77	52	59	65	59	67	74
DRAWER FRONT – 16.5" WIDE																	
DRWF1606	30	32	31	39	33	42	36	45	57	64	72	42	48	53	57	64	72
DRAWER FRONT – 18" WIDE																	
DRWF1806	30	34	32	40	35	44	37	47	59	67	74	45	51	57	58	65	73
DRWF1810	36	42	40	50	44	55	51	64	70	79	88	52	59	65	73	82	92
DRWF1812	38	42	42	53	46	58	55	69	73	82	92	56	63	70	76	86	95
DRWF1815	37	40	44	55	48	60	67	84	68	77	85	57	64	72	66	74	83
DRAWER FRONT – 21" WIDE																	
DRWF2106	33	37	37	47	38	48	38	48	68	77	85	49	55	62	62	70	78
DRWF2110	41	44	44	55	48	60	52	65	77	87	97	57	64	72	78	88	98
DRWF2112	44	47	46	58	51	64	56	70	81	91	102	60	68	75	81	91	102
DRWF2115	41	44	45	57	51	64	67	84	83	93	104	57	64	72	77	87	97
DRAWER FRONT – 24" WIDE																	
DRWF2403	35	37	38	48	41	52	45	57	50	56	63	46	52	58	47	53	59
DRWF2406	34	40	38	48	40	50	40	50	70	79	88	52	59	65	65	73	82
DRWF2410	43	46	47	59	51	64	54	68	82	92	103	65	73	82	87	98	109
DRWF2412	46	49	50	63	54	68	58	73	87	98	109	66	74	83	88	99	110
DRWF2415	53	56	69	87	76	95	117	147	118	133	148	88	99	110	105	118	132
DRAWER FRONT – 27" WIDE																	
DRWF2706	37	43	40	50	44	55	57	72	74	83	93	55	62	69	68	77	85
DRAWER FRONT – 30" WIDE																	
DRWF3006	41	47	48	60	49	62	59	74	87	98	109	61	69	77	75	84	94
DRWF3012	58	62	66	83	71	89	92	115	110	124	138	78	88	98	102	115	128
DRAWER FRONT – 33" WIDE																	
DRWF3312	61	63	68	85	74	93	93	117	115	129	144	83	93	104	108	121	135
DRAWER FRONT – 36" WIDE																	
DRWF3603	49	53	50	63	54	68	59	74	66	74	83	60	68	75	62	70	78
DRWF3606	45	51	51	64	55	69	61	77	94	106	118	69	78	87	79	89	99
DRWF3612	63	67	72	90	77	97	95	119	121	136	152	94	106	118	116	130	145
DRAWER FRONT – 39" WIDE																	
DRWF3906	45	51	51	64	55	69	61	77	94	106	118	69	78	87	79	89	99
DRAWER FRONT – 42" WIDE																	
DRWF4203	61	66	63	79	68	85	74	93	81	91	102	75	84	94	78	88	98
DRWF4206	50	58	55	69	59	74	65	82	102	115	128	76	86	95	88	99	110
DRAWER FRONT – 48" WIDE																	
DRWF4806	51	61	62	78	63	79	71	89	113	127	142	88	99	110	91	102	114