




To create the design, start with F396 and add MICROWN8/PSMICROWN8 and MROPE8 insert.




To create the design, start with MCTB8, add MBAT8 and another MCTB8 and support with cleat.




To create the design, start with F396 and add MFOLCR8/PSMFOLCR8 and MDENTIL8 insert.



To create the design, start with F396 and add MFOLCR8/PSMFOLCR8 and MROPE8 insert.



To create the design, start with MBS8 and add MCROWN8/PSMCROWN8 and support with cleat.



To create the design, start with MTST8/PSMTST8 and add F396 cut to 1 1/2" and add another MTST8/PSMTST8 and support with cleat.